

VELUREX Metal Lack

Metallized glossy wax for the intense maintenance of lacquered wooden floors



Description

VELUREX Metal Lack is a pre-metallized wax for the maintenance of ruined and/or abraded lacquered wooden floors and resilient, resin floors. Because of its polymeric structure, it gives to the surface treated an even glossy look. The film of VELUREX Metal Lack is characterised by long lasting, hardness and transparency. Available in the NO SLIP version, with non-slippery properties.

Characteristics

Application temperature	+10°C ÷ +25°C
Application	microfiber cloth
Thinning (if necessary)	water
Coverage	1 L / 70 m ²
Storage stability	1 year ⁽¹⁾
Packaging	1 L
Tool cleaning	water

1 in original sealed containers at temperatures between +10°C and +25°C

How to use

Clean very well the floor with VELUREX Cleaner Star and let it dry. Spread VELUREX Metal Lack uniformly and evenly on the surface using a microfiber cloth. For particularly heavily used floors apply a second coat of VELUREX Metal Lack after the first coat has completely dried. After some applications of VELUREX Metal Lack it is advisable to remove the old layers of wax with VELUREX DEWACHS (see technical data sheet), rinse very well with clean water and let it dry. Proceed with the application of VELUREX Metal Lack from the beginning.

Warning: Keep out of children's reach. Do not drink nor inhale. Avoid contact with eyes.

Label elements

· Causes serious eye irritation. · Causes skin irritation. · Very toxic to aquatic life with long lasting effects.

· Contains 1,2-benzisothiazol-3(2H)-one ; 2-methyl-4-isothiazolin-3-one ; Resinacids and Rosin acids, fumarated, esters with pentaerythritol. May produce an allergic reaction.

· If medical advice is needed, have product container or label at hand. · Keep out of reach of children. · Wash thoroughly with water after use. · Wear protective gloves / protective clothing / eye protection / face protection. · IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. · If eye irritation persists: Get medical advice / attention.



Web link

Be sure to have the latest version of this technical data sheet downloadable also from the following link:



http://www.chimiver.com/tds/EN_VELUREX_Metal_Lack.pdf